SEE

SOLIGOR

MOVIE LENSES

AT BETTER DEALERS

EVERYWHERE!

SOLIGOR 135MM F:4.5 TELEPHOTO

FOR ARGUS C-3 CAMERAS

IMPORTED BY

ALLIED-IMPEX

CORPORATION

NEW YORK 11, N.Y.

ONLY
$49.95

BUILT TO SOLIGOR STANDARDS

A Triumph in Optical Engineering!

- HIGHEST OPTICAL QUALITY
- EDGE–TO–EDGE SHARPNESS
- HARD COATED GLASS/AIR SURFACES
- HIGHLY COLOR CORRECTED
- DEPTH OF FIELD SCALE
- FOCUSES 8 FT. TO INFINITY (∞)
- SUPPLIED WITH FILTER-HOLDING LENS HOOD AND CLIP-ON MASK FOR YOUR VIEWFINDER

Easy to Install...

To Set Engraved Scale for Viewing From Top of Camera

1. Release set screws on geared coupling ring.
2. Unscrew ring from lens by turning counter-clockwise (with rear of lens facing you).
3. Screw lens into camera firmly.
4. Loosen 3 set screws on lens mount, and lens will freely rotate into desired position.
5. Tighten 3 set screws firmly.
6. Unscrew lens from camera.
7. Replace geared coupling ring and tighten its set screws.

To Couple With R.F...

1. Mount lens on camera.
2. Set lens and camera R. F. dial at (∞) infinity.
3. Replace center coupling gear on camera and lock into place with cover screw.
4. For focusing, rotate lens, not R.F. dial, but view through R.F. window for proper focus.

IF BACK FOCUS ADJUSTMENT IS NEEDED
Remove the geared ring that couples the rangefinder and you will see a black ring held by red screws. Mount your Soligor Telephoto Lens to the camera and loosen these red screws. Open the camera back and insert a piece of ground glass in the film channel. Set the shutter on Bulb. Set the lens at infinity and focus through the ground glass at a subject at infinity until that subject is sharp — then tighten the red screws.

I N S T R U C T I O N S

ELITAR-SOLIGOR 135mm f:4.5 LENS for ARGUS C_2, C_3

1- Set footage distance of camera at infinity

2- Remove screw covering center camera gear (between rangefinder and lens) by turning counter-clockwise.

3- Remove normal ARGUS lens by turning counter-clockwise.

4- Holding front of ELITAR-SOLIGOR lens facing you, turn (1) counter-clockwise until it stops. Push (2) toward (1) so that (2) may be freely turned.

5- Set lens at infinity, and screw in until it stops.

6- Replace center camera gear (with camera rangefinder set at infinity) and turn the first thread of the coupling gear on the lens to mesh with gear of camera.

7- Turn locking ring (1) clockwise to lock into permanent position.

IMPORTED & GUARANTEED BY:

A L L I E D - I M P E X C O R P O R A T I O N

28 West 22nd Street - New York 10, N.Y.

NOTE* To remove lens from camera:
a- Hold camera firmly in one hand.
b- Grip lens firmly, both chrome and Ring (1) with other hand.
c- Now proceed to unscrew lens counter clockwise.